


CLUB CAR REGEN 2 MODEL WIRING DIAGRAM



NOTE:
 1.) IF EQUIPPED WITH DYNAMIC BRAKING SOLENOID, REMOVE BOTH #6 WHITE WIRES. USING ONE OF THE WHITE WIRES, CONNECT A2 OF THE CONTROL TO A2 OF THE MOTOR. DISCARD THE OTHER WHITE WIRE (AS SHOWN BY THE DOTTED LINE).
 2.) CONNECT F1 OF THE MOTOR TO F2 OF THE CONTROL AND F2 OF THE MOTOR TO F1 OF THE CONTROL.